# **Technical Bulletin**



SURTECO Laminates Chemical & Disinfection Resistance Updated: June 2025

### Subject:

Guidance for Disinfection of Paper, 2D and 3D Laminates, including SPHERA 2D and 3D, and surf(x) 3D Laminates.

#### **Disinfectant Use:**

A clean surface is more important now than ever. Substrates that can be repeatedly cleaned to combat ongoing exposure to pathogens is critical. A stringent program of cleaning and disinfecting has been proven to reduce the incidence of infectious diseases. In laboratory testing using the ASTM D3450 test method, our Laminates were shown to have no discoloration or damage to the finish when repeatedly cleaned and disinfected with the following cleaners and disinfectants listed on pages 2 and 3.

The EPA published a list of disinfectants that meet its criteria for use against SARS-CoV-2, the novel coronavirus that causes COVID-19. OMNOVA\* has tested disinfectants that are approved for use against SARS-CoV-2 on its Laminates. Those approved for use against SARS-CoV-2 are in blue, bolded font on the following page. For general product cleanability information, please see Product Information Sheets.

## **Recommended Disinfectants\***

Disinfectant	Surf(x) 3DL	3DL	2DL	Paper Laminates- Woodgrains
Asepticare™	✓	<b>✓</b>	<b>√</b>	<b>✓</b>
Asepticare™TB-II	<b>✓</b>			
AVISTAT-D™Ready To Use Spray Disinfectant Cleaner	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Biotrol BirexSE®	<b>✓</b>			
Bleach 1:5 (20% bleach)	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Bleach-Rite® Disinfecting Spray	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
CaviCide™(Metrix)	<b>✓</b>			
CaviCide™ AF (Metrix)	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
CleanCide®RTU (Wexford Labs)				<b>✓</b>
CleanCide® Wipes (Wexford Labs)				<b>✓</b>
Clorox®Broad Spectrum Quaternary Disinfectant Cleaner	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Clorox®Clean-Up®Cleaner+Bleach	<b>✓</b>	<b>✓</b>	<b>√</b>	<b>✓</b>
Clorox Healthcare® Bleach Germicidal Cleaner	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Clorox Healthcare® Bleach Germicidal Wipes	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Clorox Healthcare® Citrace® Hospital Disinfectant and Deodorizer	<b>✓</b>			
Clorox Healthcare® EZ-KILL® Wipes	<b>✓</b>			
Clorox Healthcare® VersaSure® Cleaner Disinfection Wipes	<b>✓</b>			
Clorox®Hydrogen Peroxide Disinfecting Cleaners	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Dispatch® Hospital Cleaner Disinfectant with Bleach	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Diversey <sup>™</sup> Accel <sup>®</sup> INTERVention Wipes	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Diversey™Accel®TB	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
ERC Performance Wipes	<b>✓</b>	<b>✓</b>	<b>✓</b>	
FADE-A-DYNE II	<b>✓</b>			
HaloMist™	<b>✓</b>			
Isopropanol (70%)	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Isopropanol (91%)	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Lysol® Disinfectant Spray	<b>✓</b>			
McKesson™ Disposable Germicidal Surface Wipes	<b>✓</b>	<b>✓</b>	<b>✓</b>	
McKesson™ Pro-Tech RTU Disinfectant Cleaner	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Micro-Chem Plus™	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
OPTIM®1 Wipes	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>

<sup>=</sup> Approved disinfectants for use against SARS-CoV-2 per the EPA

<sup>\*</sup>Customer is solely responsible for determining whether a cleaning product is appropriate for their particular use and situation.

Product should not be used in UV disinfection/UV light cleaning areas.

## Recommended Disinfectants (Continued)\*

Disinfectant	Surf(x) 3DL	3DL	2DL	Paper Laminates- Woodgrains
OPTIM® 33TB	<b>√</b>	<b>✓</b>	<b>✓</b>	✓
Oxivir® 1 RTU	<b>✓</b>			
Oxivir∘TB	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Oxycide™ Daily Disinfectant Cleaner (Ecolab)	<b>✓</b>	<b>✓</b>	<b>✓</b>	
Powerquat™ Quaternary Ammonium (Agar)	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Precise Hospital Foam Cleaner Disinfectant (Caltech)	<b>✓</b>			
Precise QTB Spray (Caltech)	✓	✓	✓	✓
Sani-Cloth® AF3 Germicidal Disposable Wipes (PDI)	✓	✓	✓	
Sani-Cloth® HB (PDI)	✓	✓	✓	✓
Sani-Cloth® Plus (PDI)	✓	✓	✓	✓
Sani-Cloth® Plus Germicidal Disposable Cloth (PDI)	✓	✓	✓	✓
Sani-Kleen Broad-Cide 128	✓			
SaniZide® Plus 9 (Safetec)	✓	<b>✓</b>	✓	✓
Santimine 150	✓			
Super Sani-Cloth® (PDI)	✓	✓	✓	
Super Sani-Cloth® Bleach Germicidal Disposable Wipes (PDI)	✓	<b>✓</b>	✓	<b>✓</b>
Virex®II 256 (Diversey)	✓			✓
Virox AHP 5	<b>✓</b>	✓	✓	<b>✓</b>
Virox PREempt RTU	✓	✓	✓	✓
Wex-Cide 128	✓			

<sup>=</sup> Approved disinfectants for use against SARS-CoV-2 per the EPA

For the latest designs, more information, or to place an order, contact SURTECO: 866-332-5226 • laminates@surteco.com • www.surteco.com/northamerica/laminates



North American HQ 32125 Solon Rd Suite 150 Solon, OH 44139 United States

<sup>\*</sup>Customer is solely responsible for determining whether a cleaning product is appropriate for their particular use and situation.

Product should not be used in UV disinfection/UV light cleaning areas.